


Viking Tent—Timber Parts List

30 mm dowel 2.4meters

Drill a hole 100mm from end and another 60mm from end



70x35 non structural pine—2.4 meters x2

Cut 100mm by 20mm sections on each side then round to 30mm




90x19 pine—2.4 meters x2

Drill a 30mm hole 90mm from each end



190x19 pine—3.0 meters

Cut down 300 mm from either end and then down the center of the timber
Drill holes 90mm from either “end”.



Carve dragon head into the large section of each timber.
Carve or paint spiral pattern onto timber.

